

# S6 Option



P.O. Box 15732  
Brooksville, FL 34604  
Phone: 888-987-8877  
Fax: 850-654-3844  
www.surgesuppression.com

The S6 option is the surge counter option. The surge counter features a 6-digit LCD display, and a manual reset switch. The surge counter sensing circuit is current-based rather than voltage-based. That is, it only counts surges that the unit has acted upon by detecting surge current flowing into the device. This option is available on most models either integrated or externally mounted on a separate panel. It has provisions for use in NEMA 4 and NEMA 4X locations.

